

When is a Peak a Peak?


and Other Uses of Signal-to-Noise Ratios
in μ -XRF Analysis

Troy J. Ernst

Additional Contributing Authors: Ela Bakowska, Stefan Becker, Ted Berman, JoAnn Buscaglia, Christopher Hanlon, Robert Koons, Tiffany Eckert-Lumsdon, Randall Nelson, Kristine Olsson, Chris Palenik, Edward Chip Pollock, Scott Ryland, Tatiana Trejos, Melissa Valadez, Vincent Zdanowicz, and Jose Almirall

Rationale of topic

- Elemental Analysis Working Group discussion in 2010
 - Need for ***standardization***
 - Could signal-to-noise ratios (SNRs) help?



Overview of presentation

- Definitions of terms
- Reasons to calculate signal-to-noise ratios
- How to calculate signal-to-noise ratios

CAUTION: STATISTICS AHEAD

The contents on the following pages contain numerical information and descriptions that are known by the State of Michigan to cause headaches, blurred vision, and disrupted sleep patterns.


Definitions:

Signal-to-Noise Ratio (SNR)

Signal = peak area

Noise = standard deviation of the baseline when analyte is absent

$$\text{SNR} = \text{Signal} / \text{Noise}$$




Definitions:

SNR for XRF

Signal = peak area

“Noise” = $\sqrt{\text{background counts under the peak of interest}}$



$$\text{SNR} = \text{Signal} / \text{“Noise”}$$

- 1975 IUPAC spectrochemical nomenclature rules

Definitions: Limit of Detection (LOD)

Lowest concentration of an analyte that
can be ***reliably detected***

$$\text{LOD: SNR} = 3$$

- 1975 IUPAC nomenclature rules;
1980 ACS paper in *Analytical Chemistry*
- ~90% confidence level that the analyte
is present

DEFINITIONS:

Limit of Quantitation (LOQ)

Lowest concentration of an analyte that
can be ***reliably quantified***

$$\text{LOQ: SNR} = 10$$


- 1980 ACS paper

Reasons to calculate SNRs


#1: When is a peak a peak?

- Peak labels
 - 1975 IUPAC rules:
 - SNR ≥ 3 : peak**
 - Caveat 1: Cr, Cu, Zn
 - Caveat 2: shoulder peaks
 - Caveat 3: Interference from other elements

C
o
u
n
t
s



Eagle III 100- μ m moncap; 1500
LSec, 50 kV, 1000 μ A, 35 μ sec



Eagle III 100- μ m monicap; 1500
LSec, 50 kV, 1000 μ A, 35 μ sec


Reasons to calculate SNRs

#2: Should I use it in a ratio?

- Selection of elements for ratio comparisons
 - Application of 1980 ACS Guidelines
 - LOQ: SNR of 10 (reliably quantified)
 - SNR \geq 10 may be used for ratios**
 - Same caveats apply

Which of these elements should be used in ratios?

Al, Ti, Mn, Rb, Sr, Zr




Which of these elements should be used in ratios?

Al, Ti, Mn, Rb, Sr, Zr

SNR

| | | |
|----|----|----|
| Al | 15 | 22 |
| Ti | 22 | 20 |
| Mn | 12 | 11 |
| Rb | 13 | 10 |
| Sr | 13 | 12 |
| Zr | 14 | 20 |




Eagle III 100- μ m moncap; 1500
LSec, 50 kV, 1000 μ A, 35 μ sec

Reasons to calculate SNRs

#3: How low can you go?

- Estimate limits of detection in standard glasses

$$\text{LOD (ppm)} = \frac{3 * \text{given concentration (ppm)}}{\text{SNR}}$$



Average LODs of three glass standards NIST 1831, FGS-1, FGS-2

| <u>Elem</u> | <u>LOD (ppm)</u> |
|-------------|------------------|
| Na | 6979 |
| Mg | 1587 |
| Al | 854 |
| K | 129 |
| Ca | 60 |
| Ti | 28 |
| Mn | 17 |
| Fe | 14 |
| Rb | 7.0 |
| Sr | 7.0 |
| Zr | 5.3 |

(100- μ m monicap, 1200 LSec)

Reasons to calculate SNRs

#4: How do XRF systems compare?

- Compare LODs of standard glass samples run on different instruments

LODs (ppm) for three different configurations

| | A | B | C |
|-----------|-------------------------------|------------------------------------|-------------------------------|
| | Monocap, 100 μm | Polycap, 30- μm spot | Monocap, 300 μm |
| Mg | 1521 | 697 | 633 |
| Al | 874 | n/a | 445 |
| K | 138 | 57 | 62 |
| Ca | 59 | 16 | 29 |
| Ti | 29 | 15 | 12 |
| Fe | 14 | 6.0 | 8.3 |
| Rb | 5.0 | 4.1 | 3.6 |
| Sr | 7.0 | 5.3 | 4.3 |
| Zr | 5.1 | 3.7 | 3.2 |

(NIST SRM 1831; 1200 LSec)


Unnormalized spectra
Green: Polycap, 30-micron spot
Blue: Monocap, 300-micron
Red: Monocap, 100-micron


NIST SRM 1831; 1200 LSec

Orbis PC; 50 kV, 100 μ A, 12.6 μ sec
Eagle II; 40 kV, \sim 800 μ A, 17 μ sec
Eagle III; 50 kV, 1000 μ A, 35 μ sec


C
o
u
n
t
s

155000





100-um monicap systems, NIST SRM 1831



Eagle III; 50 kV, 1000 μA, 35 μsec, 1800 LSec
 Eagle III; 50 kV, 1000 μA, 35 μsec, 1200 LSec
 Eagle III; 50 kV, 1000 μA, 35 μsec, 1200 LSec

Reasons to calculate SNRs

#5: QA/QC

- Validation (instrument or method)
 - SNR target: NIST SRM 612 elements ≥ 10
- Daily function verification
 - LOD target: Ti ≥ 50 ppm
 - [LOD of 50 ppm for Ti corresponds to SNR of 6.8 in NIST SRM 1831]


SRM 612 (nominal 50 ppm)

C
O
U
N
T
S

850

1200 LSec

Ni SNR = 8.9



Eagle III 100-um monicap; 50 kV, 1000 uA

C
O
U
N
T
S

13500

20000 LSec

Ni SNR = 41



Eagle III 100-um monicap; 50 kV, 1000 uA

Usefulness of SNRs

- When is a peak a peak?

$$\text{SNR} = 3$$

- When to use a peak in a ratio?

$$\text{SNR} = 10$$

- How low can you go?

Calculate LODs on standard glasses


- How does it compare to other systems?


Compare LODs

- QA/QC:


Meet LOD or SNR thresholds

How to Calculate SNRs






Identify channels of interest: 1394-1434




Identify channels of interest: 1394-1434

Define baseline separating signal from background



Identify channels of interest: 1394-1434


Define baseline separating signal from background




Identify channels of interest: 1394-1434

Define baseline separating signal from background

Perform signal-to-noise ratio calculations




Total counts (channels 1394-1434) = 31797



Total counts (channels 1394-1434) = 31797


Background counts = [41*(avg pre- and post-peak)] = 25938



Total counts (channels 1394-1434) = 31797

Background counts = [41*(avg pre- and post-peak)] = 25938

Signal = Total – background = 5859




Total counts (channels 1394-1434) = 31797

Background counts = $[41 * (\text{avg pre- and post-peak})] = 25938$

Signal = Total – background = 5859

Noise = Square root (background counts) = 161




Total counts (channels 1394 -1434) = 31797


Background counts = [41*(avg pre- and post-peak)] = 25938

Signal = Total – background = 5859

Noise = Square root (background counts) = 161

SNR = Signal/Noise = 36






Other SNR: Na: 27

K: 44

Ti: 7.1

Mn: 3.4

Zr: 22



References

- International Union of Pure and Applied Chemistry (IUPAC), Commission on Spectrochemical and Other Optical Procedures for Analysis, *Pure & Applied Chemistry*, 1976, 45, 99
- ACS Committee on Environmental Improvement, "Guidelines for Data Acquisition and Data Quality Evaluation in Environmental Chemistry," *Analytical Chemistry*, 1980, 52, 2242-2248.

Acknowledgments

- Michigan State Police
- The EAWG members
- NIJ grant to FIU to fund the EAWG effort 2009-DN-BX-K252.

Note: Points of view in this presentation are those of the authors and do not necessarily represent the official position of the U.S. Department of Justice

Thank you

Questions?

Troy Ernst
ernstt@michigan.gov

Supplemental Tables

Channel list used in this project

| | pre-peak | Peak range | post-peak |
|-----------|-----------|------------------|-----------|
| Na | 92-96 | 95-113 | 112-116 |
| Mg | 113-117 | 116-134 | 133-137 |
| Al | 138-142 | 142-156 | 155-157 |
| S | 211-216 | 221-241 | 246-251 |
| K | 314-318* | 321-341* | 344-348* |
| Ca | 317-321 | 349-389 | 424-428 |
| Ti | 422-431 | 436-466 | 471-480 |
| Cr | 511-521 | 526-556 | 561-571 |
| Mn | 559-569 | 574-604 | 609-619 |
| Fe | 605-615 | 620-660 | 665-675 |
| Ni | 720-727 | 732-762 | 767-774 |
| Cu | 774-784 | 789-819 | 824-834 |
| Zn | 833-843 | 848-878 | 883-893 |
| As | 1023-1033 | 1038-1068 | 1073-1083 |
| Rb | 1312-1317 | 1321-1351 | 1355-1360 |
| Sr | 1379-1389 | 1394-1434 | 1439-1449 |
| Zr | 1539-1549 | 1554-1594 | 1599-1609 |

After the completion of this project, the ranges used for K were modified to 319-322, **325-340**, and 341-344

Average Limits of Detection (ppm) for Configurations A-G

| | A | B | C | D | E | F | G |
|----|------|------|------|------|-----|------|------|
| Na | 6979 | 1744 | 2592 | 6213 | | 2337 | 5073 |
| Mg | 1587 | 657 | 653 | 1605 | | 655 | 1264 |
| Al | 854 | | 455 | 823 | | 277 | 559 |
| K | 129 | 50 | 67 | 163 | 297 | 23 | 78 |
| Ca | 60 | 16 | 28 | 66 | 167 | 16 | 54 |
| Ti | 28 | 13 | 11 | 29 | 70 | 9.0 | 23 |
| Mn | 17 | 7.9 | 9.2 | 19 | 42 | 6.6 | 15 |
| Fe | 14 | 5.8 | 7.9 | 15 | 33 | 6.7 | 13 |
| Rb | 7.0 | 5.6 | 4.3 | 7.7 | | 6.5 | 7.5 |
| Sr | 7.0 | 5.5 | 4.5 | 7.3 | 9.1 | 7.1 | 7.4 |
| Zr | 5.4 | 4.1 | 3.5 | 5.6 | | 5.7 | 5.7 |

Each value represents the average of the calculated LODs for triplicate measurements on each of three standard glass materials (NIST SRM 1831, FGS-1, and FGS-2). Configurations shown on the next page.

